

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Actyon			ECM (Engine Control Module,Diesel)	DSL D27DT/DSL D20DT	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing	
				2.3 MSE	√	√	√	√	√		
				DSL D20DT(C2I) EURO3	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding	
				DSL D20DT(C3I) EURO4	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C3I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding	
				ECM (Engine Control Module,Gasoline)	2.3 MSE	√	√	√	√	√	1.ECU Initialization
				TCM (Transmission Control Module)	AUTOMATIC TRANSAXLE		√	√	√		
					DSI 6TH	√	√	√	√		1.TCU Coding 2.TCU initialization
					DSI 4TH		√	√	√		

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			ABS (Anti-lock Braking System)	TEVES(ABS/ESP)		√	√	√	√	1.Air Bleeding 2.Sensor Initialization 3.Clearing Vehicle Coding
				TEVES(ABS)		√	√	√	√	1.Air Bleeding 2.Clearing Vehicle Coding
			SRS (Supplemental Inflatable Restraint System)	SRE-NCS		√	√			
			Four Wheel Dirve System	NEW PART TIME(16PIN)	√	√	√	√		
				NEW TOD	√	√	√	√		
			RK-STICS		√	√	√	√		
		D 2.0 DOHC(ECM (Engine Control Module)		√	√	√	√	√	1.Rail pressure initialization 2.Fuel system pressure test
			TCM (Transmission Control Module)	Automatic Transmission	√	√	√	√		
			ABS (Anti-lock Braking System)	ABS/ESP(TEVES)	√	√	√	√	√	1.Sensor Initialization 2.Vehicle Coding Erasure 3.HCU Air Bleed
				ABS(TEVES)	√	√	√	√	√	1.Vehicle Coding Erasure 2.HCU Air Bleed

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Actyon (SPORTS)			SRS (Supplemental Inflatable Restraint System)	Airbag(SRE-NCS)	√	√	√				
			Four Wheel Drive System	TCCU(new model-DI engine apply)	√	√	√	√			
			Immobilizer	IMMO						1.Immobilizer coding 2.Immobilizer Information confirmation	
				RK-STICS	√	√	√	√			
	D 2.0 DOHC			ECM (Engine Control Module)	Engine Control	√	√	√	√	√	1.Rail pressure initialization 2.Fuel system pressure test 3.VIN Writing
					Engine Control(CDPF)	√	√	√	√		
				TCM (Transmission Control Module)	DSI 4	√	√	√	√		
				ABS (Anti-lock Braking System)	ABS/ESP(TEVES)	√	√	√	√	√	1.Sensor Initialization 2.Vehicle Coding Erasure 3.HCU Air Bleed
					ABS(TEVES)	√	√	√	√	√	1.Vehicle Coding Erasure 2.HCU Air Bleed

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			SRS (Supplemental Inflatable Restraint System)	Airbag(SRE-NCS)	√	√	√			
			Four Wheel Dirve System	TCCU(new model-DI engine apply)	√	√	√	√		
				TOD(new model-DI engine apply)	√	√	√	√		
			Immobilizer	RK-STICS	√	√	√	√		
			ECM (Engine Control Module)	3.2 BOSCH	√	√	√	√		1.ECU Initialization
				3.6 VDO	√	√	√	√	√	1.ECU Initialization
				3.2 VDO	√	√	√	√	√	1.ECU Initialization
				2.8 VDO	√	√	√	√	√	1.ECU Initialization
				2.3 VDO	√	√	√	√	√	1.ECU Initialization
			TCM (Transmission Control Module)	BTRA 4TH	√	√	√	√		
				NAG		√	√			
				DC 5 AT(T-Tronic)	√	√	√	√		1.TCU Coding 2.Checking TCU Lock-Up Func 3.Check TCU Adaptation 4.TCU Scan Coding
			TGS LEVER	DC LEVER	√	√	√			
				ABS/ABS 5.3	√	√	√	√	√	1.Air Bleeding
				ABS/ABD 5.3	√	√	√	√	√	1.Air Bleeding

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
Chairman			ABS (Anti-lock Braking System)	ABS/ASR 5.3	√	√	√	√	√	1.Air Bleeding
				TEVES(ABS/ESP)	√	√	√	√	√	1.Air Bleeding 2.Sensor Initialization 3.Clearing Vehicle Coding
				TEVES(ABS)		√	√	√	√	1.Air Bleeding 2.Clearing Vehicle Coding
			SRS (Supplemental Inflatable Restraint System)	BOSCH		√	√			
				SRE-NCS	√	√	√			
			ELEC. Control Suspension	VDO		√	√	√		
				SACHS(NEW CHAIRMAN)		√	√	√		
			EAS		√	√	√	√		1.Variant Initialization 2.Air Discharge And Charge 3.Height Sensor Calibration
			EPB (Electrical Parking Brake)		√	√	√	√	√	
			IMMOBILIZER		√					
Drive Control System			ECM (Engine Control Module)	G36(VDO)	√	√	√	√	√	1.ECU Initialization
				G32(VDO)	√	√	√	√	√	
				G50(BOSCH)	√	√	√	√	√	1.VIN Writing
			TCU NAG 7TH	√	√	√	√		1.TCU Initialization	

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
Chairman W			Drive Control System	TGS(DURA)	√	√	√	√	√	
			Chassis Control System	ESP	√	√	√	√	√	1.Sensor Calibration 2.Exhaust Gas Test 3.Air Bleeding
				ECS	√	√	√	√	√	
				ACC	√	√	√	√		
				SSPS	√	√	√	√		
				SAS	√	√	√	√		1.SAS Calibration
				EAS	√	√	√	√	√	1.Variant Initialization
				EPB	√	√	√	√	√	
				TPMS	√	√	√	√		
			BCM (Body Control Module)	BCM(Body Control Module)	√	√	√	√	√	1. BCM Calibration
				FAM(FRONT AREA MODULE)	√	√	√	√	√	
				RAM(REAR AREA MODULE)	√	√	√	√	√	
				DDM(DRIVER DOOR MODULE)	√	√	√	√	√	1.Door Module Calibration
				PDM(PASS. DOOR MODULE)	√	√	√	√	√	1.Door Module Calibration
				RLDM(REAR LH DOOR MODULE)	√	√	√	√	√	1.Door Module Calibration 2.Roller Initialization
				RRDM(REAR RH DOOR MODULE)	√	√	√	√	√	1.Door Module Calibration 2.Roller Initialization
			MFM(MULTI FUNC. MODULE)	√	√	√	√	√		

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
				PCM(Power Control Module)		√	√				
				ICM(Cluster)				√	√		
				DSM(DRIVER SEAT MODULE)	√	√	√	√	√		
				PSM(PSAA. SEAT MODULE)	√	√	√	√	√		
				RSM(REAR SEAT MODULE)	√	√	√	√	√		
				FATC	√	√	√				
				GWM(GATE WAY MODULE)	√	√	√				
				RASM(REAR ARMREST MODULE)	√	√	√				
				AIRBAG	√	√	√				
				AV System	CDM(Harmannavis)	√	√	√	√		
					CD(KalosNett)	√	√	√			
					AMP	√	√	√			
					TV TUNER	√	√	√			
					DMB	√	√	√			
				Istana			ECM (Engine Control Module,Gasoline)	2.3 DOHC MANUAL T/M(HFM)	√	√	√
2.8 MSE	√	√	√					√	√	1.ECU Initialization	
ABS (Anti-lock Braking System)	14 PIN Connector		√				√	√			
	20 PIN Connector		√				√	√	√	1.Air Bleeding	

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			ECM (Engine Control Module,Diesel)	DSL D27DT/DSL D20DT	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing
				DSL D27DT(C2I) EURO3	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding
				DSL D20DT(C2I) EURO3	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding
				DSL D27DT(C3I) EURO4	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C3I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Kyron				DSL D20DT(C3I) EURO4	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C3I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding	
				ECM (Engine Control Module,Gasoline)	3.2 MSE	√	√	√	√	√	1.ECU Initialization
					2.3 MSE	√	√	√	√	√	1.ECU Initialization
				TCM (Transmission Control Module)	DC 5 AT(T-TRONIC)	√	√	√	√		1.TCU Coding 2.Checking TCU Lock-Up Func 3.Check TCU Adaptation 4.TCU Scan Coding
					DSI 6TH	√	√	√	√		
					DSI 4TH		√	√	√		
				ABS (Anti-lock Braking System)	TEVES(ABS/ESP)		√	√	√	√	1.Air Bleeding 2.Sensor Initialization 3.Clearing Vehicle Coding
					TEVES(ABS)		√	√	√	√	1.Air Bleeding 2.Clearing Vehicle Coding

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			SRS (Supplemental Inflatable Restraint System)	SRE-NCS	√	√	√			
			Four Wheel Dirve System	NEW PART TIME(16PIN)	√	√	√	√		
				NEW TOD	√	√	√	√		
			SSPS		√	√	√	√		
			EAS		√	√	√	√		1.Air Discharge And Charge 2.Height Sensor Calibration
			EPB (Electrical Parking Brake)		√	√	√	√	√	
			RK-STICS		√	√	√	√		
			ECM (Engine Control Module,Gasoline)	3.2 MSE		√	√	√	√	1.ECU Initialization
				2.3 MSE		√	√	√	√	1.ECU Initialization
				3.2 D A/T	√	√	√	√	√	
				3.2 D M/T	√	√	√	√	√	
				3.2 D A/T, L/D	√	√	√	√	√	
				3.2 D M/T, L/D	√	√	√	√	√	
				2.3 D A/T	√	√	√	√	√	
				2.3 D M/T	√	√	√	√	√	
				2.3 D ASC	√	√	√	√	√	
				2.0 D A/T	√	√	√	√	√	
				2.0 D M/T	√	√	√	√	√	
				2.0 D ASC	√	√	√	√	√	

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
Korando			TCM (Transmission Control Module)	20/14PIN CONNECTOR		√	√	√		
				16PIN CONNECTOR		√	√	√		
			ABS (Anti-lock Braking System)	ABS 5.0		√	√	√	√	1.Air Bleeding
				ABS/ABD 5.0		√	√	√	√	1.Air Bleeding
				ABS/EBD 5.3		√	√	√	√	1.Air Bleeding
			SRS (Supplemental Infl)	ABD/EBD 5.3		√	√	√	√	1.Air Bleeding
				SRS(16PIN)	√	√	√			
			SRS(20PIN)	√	√	√				
			Four Wheel Dirve System	TOD		√	√			
			ELEC. Control Suspension		√	√	√	√	√	
RK-STICS		√	√	√	√					
Korando C			ECM (Engine Control Module,Diesel)	D20DTF	√	√	√	√	√	1.Variant Coding 2.CDPF 3.Injector Correction 4.Rail Pressure Control 5.VIN Writing 6.Injector Coding
										TCM (Transmission Control Module)
			Chassis Control System	MANDO(ABS/ESP)	√	√	√	√	√	1.Air Bleeding
				E-Coupling	√	√	√	√		
				EPS	√	√	√	√		1.Variant Coding 2.Steering Initialization

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
			BCM (Body Control Module)	BCM(Body Control Module)	√	√	√	√	√		
				SKM	√	√	√	√			
				AIRBAG	√	√	√				
Korando Sports			ECM (Engine Control Module,Diesel)		√	√	√	√	√	1.Variant Coding 2.CDPF 3.Injector Correction 4.Rail Pressure Control 5.VIN Writing 6.Injector Coding	
				TCM (Transmission Control Module)	DSI 6TH	√	√	√	√		1.TCU Coding 2.TCU Reset
				Four Wheel Dirve System	NEW P/TIME(16PIN)	√	√	√	√		
				Chassis Control System	MANDO(ABS/ESP)	√	√	√	√	√	1.Air Bleeding
				BCM (Body Control Module)	AIRBAG	√	√	√			
					RK-STICS	√	√	√	√		
			ECM (Engine Control Module)		√	√	√	√	√	1.Initialization and Re-Learning	
				TCM (Transmission Control Module)		√	√	√	√		1.Lock-Up Reactivation and Force Unlock
				ABS (Anti-lock Braking System)	ESP (TEVES)	√	√	√	√	√	1.Sensor Initialization 2.Vehicle Coding Erasure 3.HCU Air Bleed

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Korando Turismo			System	ABS (TEVES)	√	√	√	√	√	1.Vehicle Coding Erasure 2.HCU Air Bleed	
				SRS (Supplemental Inflatable Restraint System)	√	√	√				
				BCM (Body Control Module)	√	√	√	√	√	1.BCM Initialization	
				Smart Key System	√	√	√	√			
Musso			ECM (Engine Control Module,Gasoline)	3.2 MSE	√	√	√	√	√	1.ECU Initialization	
				2.3 MSE	√	√	√	√	√	1.ECU Initialization	
				3.2 D A/T	√	√	√	√	√		
				3.2 D M/T	√	√	√	√	√		
				3.2 D A/T, L/D	√	√	√	√	√		
				3.2 D M/T, L/D	√	√	√	√	√		
				2.3 D A/T	√	√	√	√	√		
				2.3 D M/T	√	√	√	√	√		
				2.3 D ASC	√	√	√	√	√		
				2.0 D A/T	√	√	√	√	√		
				2.0 D M/T	√	√	√	√	√		
				2.0 D ASC	√	√	√	√	√		
				TCM (Transmission Control Module)	20/14PIN CONNECTOR		√	√	√		
					16PIN CONNECTOR		√	√	√		
				ABS (Anti-lock Braking)	ABS 5.0		√	√	√	√	1.Air Bleeding
					ABS/ABD 5.0		√	√	√	√	1.Air Bleeding

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			System)	ABS/EBD 5.3		√	√	√	√	1.Air Bleeding
				ABD/EBD 5.3		√	√	√	√	1.Air Bleeding
			Four Wheel Dirve System	TOD		√	√			
			ELEC. Control Suspension		√	√	√	√	√	
			HUBER EGR		√	√	√			
			IMMOBILIZER		√					
				DSL D27DT	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing
				DSL D27DT(C2I) EURO3)	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing 5.ECU Coding
				DSL D27DT(C3I) EURO4	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C3I) 3.Miscellaneous 4.VIN Writing 5.ECU Coding

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			ECM (Engine Control Module,Diesel)	DSL D20DT(C3I) EURO4	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C3I) 3.Miscellaneous 4.VIN Writing 5.ECU Coding
				CDPF(C2I)	√			√		1.DPF Regeneration 2.DPF Replacement(Reset) 3.Pressure Sensor(Reset)
				CDPF(C3I)	√			√		1.DPF Regeneration 2.DPF Replacement(Reset) 3.Pressure Sensor(Reset) 4.Excessive Regeneration (Reset) 5.Cluster Replacement
				D 2.9 SOHC	√	√	√			
			ECM (Engine Control Module,Gasoline)	3.2 MSE		√	√	√	√	1.ECU Initialization
				2.8 MSE		√	√	√	√	1.ECU Initialization
				2.3 MSE		√	√	√	√	1.ECU Initialization
				BTRA 4 A/T		√	√	√		

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Rexton			TCM (Transmission Control Module)	DC 5 AT(T-Tronic)	√	√	√	√		1.TCU Coding 2.Checking TCU Lock-Up Func 3.Check TCU Adaptation 4.TCU Scan Coding	
				DSI 6TH	√	√	√	√			
			TGS	DC LEVER	√	√	√				
			ABS (Anti-lock Braking System)	BOSCH		√	√	√	√		
				TEVES(ABS/ESP)			√	√	√	√	1.Air Bleeding 2.Sensor Initialization 3.Clearing Vehicle Coding
				TEVES(ABS)			√	√	√	√	1.Air Bleeding 2.Clearing Vehicle Coding
				ABS/ABS 5.3	√	√	√	√	√	1.Clearing Vehicle Coding	
				ABS/ABD 5.3	√	√	√	√	√	1.Clearing Vehicle Coding	
				ABS/ASR 5.3	√	√	√	√	√	1.Clearing Vehicle Coding	
			SRS (Supplemental Inflatable Restraint System)	SRE-6	√	√	√				
				SRE-NCS	√	√	√				
			Four Wheel Drive			NEW PARTTIME(16PIN)	√	√	√	√	

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			Four wheel Drive System	NEW TOD	√	√	√	√		1.TCCU CODING
				TOD	√	√	√			
			SSPS	√	√	√	√			
			HUBER EGR	√	√	√			1.EGR System Initialization 2.EGR System Reset 3.VIN Writing	
			EAS	√	√	√	√		1.Air Discharge And Charge 2.Height Sensor Calibration	
			EPB (Electrical Parking Brake)	√	√	√	√			
			RK-STICS	√	√	√	√			
			ECM (Engine Control Module)	DSL D27DT/DSL D20DT	√	√	√	√	√	1.Leak Detection 2.Injector Coding(C2I) 3.Rail Pressure Initialization 4.VIN Writing
				3.2 MSE	√	√	√	√	√	1.ECU Initialization

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions						
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions	
Rudius/Stavic			TCM (Transmission Control Module)		√	√	√	√		1.TCU Coding 2.Checking TCU Lock-Up Func 3.Check TCU Adaptation 4.TCU Scan Coding	
			ABS (Anti-lock Braking System)	TEVES(ABS/ESP)			√	√	√	√	1.Air Bleeding 2.Sensor Initialization 3.Clearing Vehicle Coding
				TEVES(ABS)			√	√	√	√	1.Air Bleeding 2.Clearing Vehicle Coding
			TGS LEVER	DC LEVER	√	√	√				
			SRS (Supplemental Inflatable Restraint System)	SRE-NCS	√	√	√				
			Four Wheel Dirve System	NEW PART TIME(16PIN)	√	√	√	√			
				NEW TOD	√	√	√	√			1.TCCU CODING
			EAS		√	√	√	√			1.Air Discharge And Charge 2.Height Sensor Calibration
			EPB (Electrical Parking Brake)		√	√	√	√	√		

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
			RE-STICS		√	√	√	√		
			RK-STICS		√	√	√	√		
TIVOLI	2016	D1. 6DOHC	ECM(Engine Control Module)		√	√	√	√	√	
			TCM(Transmission Control Module)		√	√	√	√		
			ABS(Anti-lock Braking System)		√	√	√	√	√	
			SRS(Supplemental Inflatable Restraint System)		√	√	√	√		
			BCM(Body Control Module)		√	√	√	√	√	
			EPS(Electronic Power Steering)		√	√	√	√		
			TPMS(Tire Pressure Monitoring System)		√	√	√	√		
			Smart Key Unit		√	√	√	√		
		Gcu								
		ECM(Engine Control Module)		√	√	√	√	√		
		TCM(Transmission Control Module)		√	√	√	√			
		ABS(Anti-lock Braking System)		√	√	√	√	√		
		SRS(Supplemental Inflatable Restraint System)		√	√	√	√			
		BCM(Body Control Module)		√	√	√	√	√		
	EPS(Electronic Power Steering)		√	√	√	√				
	TPMS(Tire Pressure Monitoring System)		√	√	√	√				
	Smart Key Unit		√	√	√	√				
	ECM(Engine Control Module)		√	√	√	√	√			
	TCM(Transmission Control Module)		√	√	√	√				
	ABS(Anti-lock Braking System)		√	√	√	√	√			
	SRS(Supplemental Inflatable Restraint System)		√	√	√	√				

SsangYong V18.90 Diagnostics List (Note:For reference only)

Vehicle	year	Enginedesc	System	Sub system	Functions					
					System Info.	Read Dtc	Clear Dtc	Data stream	Actuation	Special Functions
	2015	G1. 6DOHC	BCM(Body Control Module)		√	√	√	√	√	
			EPS(Electronic Power Steering)		√	√	√	√		
			TPMS(Tire Pressure Monitoring System)		√	√	√	√		
			Smart Key Unit		√	√	√	√		
			Gcu							
		G1. 6DOHC	ECM(Engine Control Module)		√	√	√	√	√	
			TCM(Transmission Control Module)		√	√	√	√		
			ABS(Anti-lock Braking System)		√	√	√	√	√	
			SRS(Supplemental Inflatable Restraint System)		√	√	√	√		
			BCM(Body Control Module)		√	√	√	√	√	
	EPS(Electronic Power Steering)			√	√	√	√			
	TPMS(Tire Pressure Monitoring System)			√	√	√	√			
	Smart Key Unit		√	√	√	√				

(*):Tested;

(?):Manual on website(www.x431.com)

The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.